

Tank Angle Valves - Above Ground Tanks

| | |
|---------------------------------|---|
| Application: | Tank angle valves are normally connected directly to the outlet on above ground fuel storage tanks; they are used to control the gravity flow of fuel from the tank, to the fuel dispensing nozzle. |
| Standards: | Manufactured to connect to NPT threaded hose & tank connections |
| Materials: | Bayloy body, zinc cap and Buna seal Please note: all fuels contain additives, which can vary by fuel brand and season. Please contact Dixon with a list of all additives and we will advise of any known compatibility issues. |
| Features & Benefits: | <ul style="list-style-type: none"> • Pad lockable (lock not included) • Easily control flow by rotating cap |



| Size | Description | Part # |
|--------|---------------------------|--------------|
| 1" | Female NPT inlet & outlet | 500AV |
| 1-1/4" | Female NPT inlet & outlet | 525AV |

- See page 1103 for repair kit

Automatic Pressure/Vacuum Relief Caps for Stationary Tanks

| | |
|---------------------------------|--|
| Application: | These caps are threaded into the top of stationary (non-mobile) above ground fuel storage tanks, where they serve two purposes: a) they can be used as a thread in and lockable fuel filler cap. b) They protect the tank from expansion or implosion, the internal relief valve is normally closed, but opens to relieve internal pressure and vacuum. |
| Standards: | Manufactured to thread into both NPS and NPT tank openings |
| Materials: | Die cast zinc body, brass screen |
| Features & Benefits: | <ul style="list-style-type: none"> • Normally closed vent stops fuel evaporation and airborne contaminants • Protects tank from pressure and vacuum build-up. Relieves pressure at 2 PSI and vacuum at 0.7 HG at a rate of 20 SCFM • Can be used as a fuel filler cap • Pad lockable to prevent fuel theft and tampering |



2500L

| Male NPT | Part # |
|----------|--------------|
| 2" | 2000L |
| 2½" | 2500L |

- Not intended for use on mobile tanks. To ensure that the cap can properly vent, the vent cap must be kept free of any debris i.e. dirt, snow, ice, rags etc.