

Expansion Rings

Features:

- These rings are used with the fire hose couplings listed on pages 813-814.

OD	Length	Wall Thickness	85/15 red brass Part #	Wt. Lbs.
1"	1-1/4"	.05	ER10125	.07
1-1/2"	3/4"	.05	ER1575	.06
1-1/2"	7/8"	.05	ER1587	.07
1-1/2"	1"	.05	ER1510	.07
1-1/2"	1-1/4"	.05	ER15125	.09
1-3/4"	1-1/4"	.05	ER17125	.12
2½"	1-1/4"	.062	ER27125	.19
2½"	1-1/2"	.062	ER27150	.21
3"	2"	.07	ER3020	.44
4"	2"	.092	ER4020	.60



Fire Hose Coupling Washers Swivel Washers

Features:

- Swivel washers are used on the swivel end of the fire hose couplings listed on pages 814-815.

ID	OD	Thickness	Buna-N Part #	Wt. Lbs.
1-1/16"	1-7/16"	1/8"	SW100F	.01
1-9/16"	2-1/16"	1/8"	SW150	.01
2-1/16"	2½"	1/8"	SW200	.02
2-9/16"	3-3/16"	3/16"	SW250	.02
3-1/16"	3-3/4"	1/4"	SW300F	.05
4-1/16"	5-1/8"	1/4"	SW400F	.09
4-9/16"	5-7/8"	1/4"	SW450F	.14
5-1/16"	6-3/8"	1/4"	SW500F	.09
6-1/16"	7-1/8"	1/4"	SW600F	.10



Tail Washers

Features:

- Tail washers are used on the tail end of the fire hose couplings listed on pages 814-815.

ID	OD	Thickness	Buna-N Part #	Wt. Lbs.
1-1/32"	1-5/16"	3/16"	STW100	.01
1-9/16"	1-3/4"	3/16"	RTW150	.01
1-9/16"	1-27/32"	3/16"	RTW151	.01
1-9/16"	1-15/16"	3/16"	STW150	.01
1-9/16"	1-29/32"	3/16"	STW151	.01
1-5/8"	2-1/8"	3/16"	DTW150	.01
1-9/16"	2-1/32"	3/16"	DTW151	.01
1-13/16"	2-1/8"	3/16"	STW175	.01
1-27/32"	2-5/16"	3/16"	DTW175	.01
2-9/16"	3"	1/4"	STW250	.02
2-9/16"	3-1/32"	1/4"	STW251	.03
2-5/8"	3-1/4"	1/4"	DTW250	.04
2-9/16"	3-5/32"	1/4"	DTW251	.03
3-1/8"	3-25/32"	1/4"	DTW300	.04

