Page #

N

N4F6 1095
Needle 273, 923
  Bleed 563, 921
  Block and bleed 563, 921
  Mini 562, 920
  Multiport 562, 920
Nipples
  3500 ..... 226, 1092
  Close 450, 941, 942, 954
  Combination 9, 10, 11, 12, 358, 359, 360, 361, 363, 383
    Jump size 360
  Filters 269
  Hex 451, 942
    Reducer 452, 942
    Straight 942
  Hex welding 965
  King® 358, 360, 361, 363, 365
  Notched turned back 361, 362
  Octagon 965
  Pipe 940, 941
  Polypropylene 954
Nitrile washdown hose 763, 764, 765
Notched
  Cam and groove fittings .. 34, 35, 42, 43
  Ferrules 362, 363
  Stems, Holedall® 363
  Turned back nipples 362
Nozzles
  Accessories
    Breakaways 1043
    Multi-plane hose swivels 1043
    Single plane hose swivels ... 1043
  Adjust-A-Power 414, 1075
  Automatic shutoff 1047
  Ball 1039
  Big Mouth™ diesel 1045
  Constant flow 414, 1077
    Displays 414, 1077
  Farm and consumer 1046
  Fire ... 779, 780, 781, 782, 783, 784, 785, 786, 787, 788, 789, 790, 791, 792, 793
  Flomax refueling 108, 109, 111, 112, 113, 114, 115
  Fog 412
  Fuel . 1039, 1040, 1041, 1044, 1045, 1046, 1047
    Cross reference 1046
  Fuel Master™ diesel 1044
  Gravity 1040, 1041
  High fow fueler 1047
  Holders 185
  Hot water washdown, spray 396
  Injector 405
  Lite washdown, spray 396
  Plain hose 414, 1077
  Pressure 1034, 1040, 1041
  Pressure washing 402
    Anti-fatigue

Page #

    Heavy duty 402
  Lances and extensions 403
    Dual spray lance 403
    Lance belt 404
    Molded grip extensions 403, 1073
    Spray lance 403
    Telescoping lance 404
    Vented grip lance 403
  Line strainer 405
  Nozzle holders 408
  Nozzles
    Injector 405
    Quick connect 406, 1071
    Quick connect, multi-pack 406, 1071
    Quick connect, soap 406
    Selection guidelines 407
    Spray chart 407
    Spray, high pressure 406, 1072
    Spray, high pressure soap .. 406
    Turbo 408, 1072
    Turbo, inlet filter 408
  Quick couplings
    Fixed plugs 405, 1071
    Swiveling 404, 1071
  Spray guns 402
    Anti-fatigue 402, 1072
    Kit with hose, nozzle & lance ... 402
    Pressure 402
    Pressure with extension 402
  Valves
    Balance release 408
    Safety release 409
    Thermal relief 409
    Unloader 409
  Water broom 408
Sewer 405
Spray 395, 397, 398
Sweeper 413, 1075
Tank truck . 1039, 1040, 1041, 1044, 1045, 1046, 1047
Temperature indicating 398
Twist 413, 1076
Washdown
  Adjust-A-Power 414, 1075
  Constant flow 414
  Elevated temperature 395
  Hot water 396, 413
  Industrial 398
  Insulated 413, 1076
  Lite 396
  Spray 397, 398
    Mini 397
  Sweeper 413, 1075
  Temperature indicating 398
  Twist 413, 1076
  Wand 397
  Water 413
  Water broom 408
Water 413, 1076
  Hot water 413

Page #

    Insulated 413, 1076
    Pistol-grip 413
    Power flow 413
    Water, flexible 413
NPT threaded fittings 958, 965
  Gaskets 958
NYFD
  Adapters 849
Nylon fittings 953, 954, 955, 956, 1008, 1019
Nylon tubing 1015, 1016

O

Octagonal nipples 966
Oil removal filter 321
Oil vapor removal filter 322
Open flex 1L couplings 968
Oxy-acetylene
  Adapters 458
  Connecting spuds 458
  Ferrules 458
  Hose couplings 458

P

Panel builder gauges 349
Parker Ez-Mate 219
Petroleum fittings, API 584
Phonograph finish fittings 363
Pinch-on clamps
  Double ear 475
  Single ear 475
  Stepless® ear 476
Pin lug 372
  Couplings 371, 1036
  Hydrant
    Adapters 412
Pipe
  Adapters ... 449, 450, 452, 934, 939, 940, 943, 953
  Bushings ... 449, 937, 938, 939, 953, 1019
  Caps 454, 951, 956
  Couplings .. 552, 953, 967, 968, 973, 974, 975, 983
    Grip-L 967
    Hex 449, 552, 936
    Merchant 935
    Open-Flex 1L 968
    Threaded 935
  Crosses 454, 950, 955
  Elbows 452, 453, 553, 944, 945, 946, 947, 949, 955
  Nipples 450, 451, 452, 551, 940, 941, 942, 954, 965, 980
  Plugs 455, 952, 956, 960
  Rapp-it repair kits 1051
  Tees .. 453, 454, 554, 948, 949, 950, 955
  Threaded bell reducers 933, 934
  Unions 936